

Moody Radio Network Relay Assignments

Effective 3-23-2015

| XDS-PRO Relays | Relay Function | Time | XDS-PRO Pinouts |
|----------------|---|----------------------|-----------------|
| Relay 1 | Program Start – Precedes all program starts | Various | 1 & 20 |
| Relay 2 | Break Start – Precedes all program breaks | Various | 2 & 21 |
| Relay 3 | Newscast Start – Precedes all hourly newscasts | Every hour at :55:00 | 3 & 22 |
| Relay 4 | Network ID -- Precedes hourly :60 Network ID | Every hour at :59:00 | 4 & 23 |
| Ground | N/A | N/A | 5 & 24 |
| Relay 5 | Satellator ID Start – Precedes hourly :30 Sponsorship/ID announcement | Every hour at :59:30 | 6 & 25 |
| Relay 6 | Moody Radio Alert – More information at: www.whereturn.org/alerts | Various | 7 & 26 |
| Relay 7 | Hourly Time Synchronization Relay for automation systems | Every hour at :54:30 | 8 & 27 |
| Relay 8 | (unused) | N/A | 9 & 28 |